


## FLILHAM Specification Sheet : H5-UNV-70HSC

70W MH M98, M139, 120-277V 50/60 Hz C139, M143



SIDE LEADS



- 1. Maximum allowable case temperature is 85°C. See Hot Spot section for measurement location.
- 2. Ignition pulse is 4kV max.
- 3. Ballast output will shutdown after 25 minutes if lamp fails to ignite.
- 4. Power must be cycled off then on, after replacing lamp.
- 5. Do not install insulation above or within 3 inches of ballast sides
- 6. Can be remotely installed up to 12 feet from lamp.

- 1. Short Circuit Operation Protection
- 2. Open Circuit Operation Protection
- 3. Ignitor Failure Protection
- 4. Thermal Protection
- 5. End of Lamp Life Protection

Fulham extends a limited warranty only to the original purchaser or to the first user for a period of <u>3 years</u> from the date of manufacture when properly installed and operated under normal conditions of use. For complete terms and conditions, please reference the Fulham product catalog (www.fulham.com). **Due to a program of continuous improvement, Fulham reserves the right to make modifications or variations in design or construction to the equipment described.**