



Unlock the power of Pico remote controls



Make your job easier, and give customers control where they need it.

What is a Pico?



Pico remote wall-mounting kit (sold separately)

Multi-location control
in a few minutes

A Pico is a battery-powered, RF remote that communicates with other Lutron wireless devices, including dimmers, switches, and shades, as well as with fans and audio integrated into a Lutron system.




Adding a Pico to a dimmer, switch, shade, fan, or Sonos Home Sound System provides an additional point of control. And it only takes a few minutes to do.

What can a Pico do for you?

- You can add a Pico to any wall surface without cutting holes, running wire, spackling, and repainting.
- You can easily add 3-way dimming or switching control where your customer needs it, in a fraction of the time and labor it takes to install a wired 3-way.
- You'll avoid callbacks. The Pico is battery-powered, with an industry-leading 10-year battery life.

Your time is valuable



15 minutes
or less


Adding a new control location with a Pico

You can add a Pico in 3 easy steps:

1. Replace an existing switch with a Lutron wireless dimmer or switch
2. Associate the Pico to the dimmer or switch*
3. Attach the Pico to a wall, place it on a pedestal, or use it with a car visor clip

Tools needed: screwdriver and pliers

* You can also easily associate a Pico directly to Lutron shades.



2-4 hours


Adding a new control location with a 3-way switch

Installing a traditional switch requires more time:

1. Run wire through a crawl space, attic, or fish through a wall
2. Cut a hole in drywall and install the wallbox
3. Wire the new control into the existing circuit
4. Repair the wall and paint it

Tools needed: screwdriver, wire stripper, drywall saw, fish tape, pliers

What can a Pico do for your customers?



With a Pico and just one touch, a customer can:

- Turn off all the lights in the house
- Control multiple lights or shades at one time
- Control audio (instead of opening an app on a phone)
- Control a ceiling fan

Control where your customer wants it

Mount a Pico on a tabletop pedestal. Tabletop pedestals are available in single, double, and triple configurations.

You can also mount a Pico on a wall.

Pico is also great problem solver —
for entry lights...



Use a Pico with a car visor clip to turn on entry or foyer lights when coming home at night, to create a path of light into the house.



The Clear Connect wireless signal works around corners/through walls and is ultra-reliable, which equals no callbacks for you.

... and nurseries,




Keep one close at hand to dim lights without getting up, when singing baby to sleep.



3-button Nightlight Pico with raise/ lower buttons
*Moon LED shown brighter than it actually appears.

... as well as hallways.



Add additional control to high traffic areas that lack a convenient control location, such as a long hallway.




2-button Lights Pico mounted in a wallplate

Pico remote control


Control lights, shades, audio, and ceiling fans. Users can create a frequently used setting, save it, and then recall it with the “Favorite” button.

Lighting control




Pico remote for lights
PJ2-3BRL-GWH-L01

Shade control




Pico remote for shades
PJ2-3BRL-GWH-S01

Audio control



Pico remote for audio
PJ2-3BRL-GWH-A02

Fan control




Pico remote for fans
PJ2-3BRL-GWH-F01

4-button Pico remote control

Control zones, scenes, or groups of lights and/or shades.

Zone control

Control multiple lights or shades; operates the same as a 3-button remote with raise/lower, but without a "Favorite" button



Lights model

PJ2-4B-GWH-L01

Scene control

Control lights or shades to preset levels; differs from a Pico scene keypad in that all devices associated to the top button will also be associated to the other three buttons.




Lights model

PJ2-4B-GWH-L31

2-group control

Control two groups of lights, two groups of shades, or one group of lights/one group of shades.



Lights model

PJ2-4B-GWH-L21

4-group toggle

Toggles four loads on and off; designed for HomeWorks QS systems



Lights model

PJ2-4B-GWH-L41


Pico scene keypads

Control lights, shades, and audio. These keypads are available pre-engraved with common scenes for typical activities in a home. They autoconfigure in the Lutron App for Caséta and RA2 Select, saving you time, and can be easily configured in the app to personalize for the homeowner.

2-button Scene control




Turn lights on to
programmed level

Turn lights off




Use the “Goodnight”
button to turn lights off
and lower shades in other
rooms of the house and
the “Alert” button to turn
hallway lights on and raise
living room shades, all
without getting out of bed.

Pico Bedside scene keypad
PJ2-2B-GWH-P02

| |  Ceiling lights |  Table lamp |  Shades |
|-------------|--|--|--|
| Home | 100% | 50% | Open |
| Away | Off | Off | Closed |

4-button Scene control




Control all the kitchen lights with a single button press.

Pico Kitchen scene keypad
PJ2-4B-GWH-P02


| |  Ceiling lights |  Island lights |  Pendant |  Shades |
|----------------|--|---|---|--|
| Bright | 100% | 100% | 100% | Open |
| Cooking | 100% | 100% | 50% | 75% Open |
| Dining | 20% | 65% | 50% | Half Open |
| Off | Off | Off | Off | Closed |

Pico remote controls for lighting

Ordering Information



Build a Pico Model Number



Button Configuration Codes:

| Button Configurations | Code |
|---------------------------|------|
| 2-button | 2B |
| 2-button with raise/lower | 2BRL |
| 3-button | 3B |
| 3-button with raise/lower | 3BRL |
| 4-button | 4B |

Button Marking Codes:

L01, L31, L21, LS21, L41

Color Codes:

| Gloss Colors | Code |
|--------------|------|
| White | GWH |
| Black | GBL |
| Ivory | GIV |
| Light Almond | GLA |
| White/Gray | GWG* |

| Satin Colors | Code |
|--------------|------|
| Snow | TSW |
| Biscuit | TBI |
| Midnight | TMN |

Pico remote controls for lighting *with nightlight*

Ordering Information



PJN-2B-GWH-L01
(actual size)



PJN-3BRL-GWH-L01
(actual size)

* Moon LED shown brighter than it actually appears.

Build a Pico Model Number

PJN- -XXX-L01

Button
Configuration
Code

Color
Code

Button Configuration Codes:

| Button Configurations | Code |
|---------------------------|------|
| 2-button | 2B |
| 3-button with raise/lower | 3BRL |

Button Marking Code:

L01

Color Codes:

| Gloss Colors | Code |
|--------------|------|
| White | GWH |
| Black | GBL |
| Ivory | GIV |
| Light Almond | GLA |




Pico remote controls for shades

Ordering Information



Build a Pico Model Number



Button Configuration Codes:

| Button Configurations | Code |
|---------------------------|------|
| 2-button with raise/lower | 2BRL |
| 3-button with raise/lower | 3BRL |
| 4-button | 4B |

Button Marking Codes:

S01, S02, S03, S04, S05, S06, S07, S09, S31, S21

Color Codes:

| Gloss Colors | Code |
|--------------|------|
| White | GWH |
| Black | GBL |
| Ivory | GIV |
| Light Almond | GLA |
| White/Gray | GWG* |

| Satin Colors | Code |
|--------------|------|
| Snow | TSW |
| Biscuit | TBI |
| Midnight | TMN |

Pico remote control for video screens

Ordering Information



PJ2-2B-GWH-S08
(actual size)

Build a Pico Model Number

PJ2-2B-XXX-S08

Color
Code





Button Configuration Codes:

| <u>Button Configurations</u> | <u>Code</u> |
|------------------------------|-------------|
| 2-button | 2B |

Button Marking Code:

S08

Color Codes:

| <u>Gloss Colors</u> | <u>Code</u> | |
|---------------------|-------------|---|
| White | GWH |  |
| Black | GBL |  |
| Ivory | GIV |  |
| Light Almond | GLA |  |



| <u>Satin Colors</u> | <u>Code</u> | |
|---------------------|-------------|---|
| Snow | TSW |  |
| Biscuit | TBI |  |
| Midnight | TMN |  |

Pico remote control for audio

Ordering Information



PJ2-3BRL-GWH-A02
(actual size)



Build a Pico Model Number

PJ2-3BRL-XXX-A02

Color
Code



Button Configuration Codes:

| Button Configurations | Code |
|---------------------------|------|
| 3-button with raise/lower | 3BRL |

Button Marking Code:

A02

Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | GWH |  |
| Black | GBL |  |

| Satin Colors | Code | |
|--------------|------|---|
| Snow | TSW |  |
| Biscuit | TBI |  |
| Midnight | TMN |  |

Pico remote control for fans

Ordering Information



PJ2-3BRL-GWH-F01
(actual size)

Build a Pico Model Number

PJ2-3BRL-XXX-F01

Color
Code

Button Configuration Codes:

| <u>Button Configurations</u> | <u>Code</u> |
|------------------------------|-------------|
| 3-button with raise/lower | 3BRL |

Button Marking Code:

F01

Color Codes:

| <u>Gloss Colors</u> | <u>Code</u> | |
|---------------------|-------------|---|
| White | GWH |  |
| Black | GBL |  |
| Ivory | GIV |  |
| Light Almond | GLA |  |

| <u>Satin Colors</u> | <u>Code</u> | |
|---------------------|-------------|---|
| Snow | TSW |  |
| Biscuit | TBI |  |
| Midnight | TMN |  |

Pico scene keypads

Ordering Information

Entry

PJ2-2B-GWH-P01
(actual size)

Bedside

PJ2-2B-GWH-P02
(actual size)

Family room

PJ2-4B-GWH-P01
(actual size)


Kitchen

PJ2-4B-GWH-P02
(actual size)

Any Room

PJ2-4B-GWH-P03
(actual size)

Build a Pico Model Number



Button Configuration Codes:

| Button Configurations | Code |
|-----------------------|------|
| 2-button | 2B |
| 4-button | 4B |

Button Marking Codes:

P01, P02, P03

Color Codes:

| Gloss Colors | Code |
|--------------|------|
| White | GWH |
| Black | GBL |
| Ivory | GIV |
| Light Almond | GLA |

| Satin Colors | Code |
|--------------|------|
| Snow | TSW |
| Biscuit | TBI |
| Midnight | TMN |

Custom 4-button Pico remote controls

Ordering Information: lutron.com/custompico

Zone Controls



PJ2-4B-GWH-EL1
(lights example)




PJ2-4B-GWH-ES1
(shades example)

Scene Controls



PJ2-4B-GWH-EL2
(lights example)



PJ2-4B-GWH-ES2
(shades example)

Build a Pico Model Number

PJ2-4B-XXX-XXX

Color
Code

Button
Marking
Code





Button Configuration Codes:

| Button Configurations | Code |
|-----------------------|------|
| 4-button | 4B |

Button Marking Codes:

EL1, EL2, ES1, ES2

Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | GWH |  |
| Black | GBL |  |
| Ivory | GIV |  |
| Light Almond | GLA |  |

| Satin Colors | Code | |
|--------------|------|---|
| Snow | TSW |  |
| Biscuit | TBI |  |
| Midnight | TMN |  |

Pico remote controls — mounting accessories

Ordering Information



L-PED1-WH



L-PED2-WH



L-PED3-WH



Pedestal Model Number

L-PEDX-XX

Capacity
Code

Color
Code

Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | WH |  |
| Black | BL |  |

Single, double, and triple pedestals available



Claro wallplate
(CW-1-WH)

- Provides a clean, screwless look
- Available in 1-6 openings



Wallplate bracket
(PICO-WBX-ADAPT)

- Use to surface-mount a Pico to a wall
- Required when mounting a Pico over a 120V wallbox



Car visor clip
(PICO-CAR-CLIP)

- Insert the Pico into the clip for convenient control from your car

Gloss Wallplate Model Number

CW- -XX

Openings

Color
Code

Satin Wallplate Model Number

SC- -XX

Openings

Color
Code

Wallplate Color Codes:

| Gloss Colors | Code | |
|--------------|------|--|
| White | WH | |
| Black | BL | |
| Ivory | IV | |
| Light Almond | LA | |

| Satin Colors | Code | |
|--------------|------|--|
| Snow | SW | |
| Biscuit | BI | |
| Midnight | MN | |

Pico remote controls — flexibility

You can use a Pico with Lutron standalone dimmers and shades, as well as with the following Lutron systems

Caséta



Pico remote, Caséta dimmer, and Serena shades

RA2 Select



Pico scene keypad, Maestro dimmer, and Sivoia QS Triathlon shades

RadioRA 2



Pico remote, seeTouch keypad, and Sivoia QS Wireless shades

HomeWorks QS



Pico remote, Palladiom keypad, and Palladiom shades

The Lutron logo, Lutron, Caséta, Claro, Clear Connect, HomeWorks, Maestro, Palladiom, Pico, RadioRA 2, RA2 Select, Satin Colors, seeTouch, Serena, Sivoia QS, and Triathlon are trademarks or registered trademarks of Lutron Electronics Co., Inc., in the U.S. and/or other countries.

Sonos and Works with Sonos are trademarks or registered trademarks of Sonos, Inc.

lutron.com/pico

Lutron Electronics Co., Inc., 7200 Suter Road, Coopersburg, PA 18036-1299

Customer Assistance

Online: lutron.com/help | Email: support@lutron.com | Phone: 1.844.LUTRON1 (588.7661) — includes 24/7 technical support

© 04/2019 Lutron Electronics Co., Inc. | P/N 367-2821 REV B

